

# UML

## Self-Balancing App-Controlled Robot

### Abstract

This document includes diagrams and descriptions on how SAR systems are going to work.

Konghon Choo and Eveline Ververgaert


11-09-2017

Version	Description	Date
0.1	Setup	08-09-2017
0.2	Use case, class diagram, state diagram, protocols	09-11-2017

## Table of content

System architecture .....	3
Use cases .....	4
Diagram .....	4
Description tables.....	4
Class diagrams .....	6
Robot .....	6
State diagram - Robot .....	7
Protocols.....	8
Identify .....	8
Update information.....	8
Instructions.....	8
Disconnect.....	9


## System architecture



This diagram displays a rough sketch of what SAR looks like on the outside. The SAR system consists of 2 parts, the App and the Robot. The user controls the robot through the app. The app and robot communicate through a WiFi module.

## Use cases

### Diagram



### Description tables

UC1	Move Robot
<b>Goal in context</b>	The robot is moved into requested direction.
<b>Preconditions</b>	The robot is on and connected (UC2).
<b>Successful end condition</b>	The robot moves into requested direction.
<b>Failed end condition</b>	The robot moves into wrong direction or doesn't move at all.
<b>Actors</b>	User, robot and app
<b>Trigger</b>	User moved the joystick forward (or another direction).

	Steps	Action
<b>Main flow:</b>	1	App sends command (e.g. direction forward) to the robot.
	2	Robot detects if there are no obstacles.
	3	Robot moves into requested direction.
<b>Exception flow:</b>	2.1	Robot detects an obstacle.
	2.2	Robot does not move.
	3.1	Robot moves into an undesired direction.

UC2	Connect
<b>Goal in context</b>	The robot and app are connected.
<b>Preconditions</b>	The robot is on.
<b>Successful end condition</b>	The robot successfully connects with the app.
<b>Failed end condition</b>	The robot fails to connect with the app.
<b>Actors</b>	User, robot and app
<b>Trigger</b>	User pressed “connect”.


	Steps	Action
<b>Main flow:</b>	1	App searches for the robot hotspot.
	2	App finds robot hotspot.
	3	App and robot use handshake technique to connect.
	4	App shows on UI it is connected.
<b>Exception flow:</b>	1.1	App is unable to find robot.
	1.2	App displays error message.
	3.1	Handshake is unsuccessful.
	3.2	Retry handshake (this step could happen multiple times under water).
	3.3	Handshake is still unsuccessful.
	3.4	App displays error message.

UC3	Show states
<b>Goal in context</b>	The app is able to display status information coming from the robot.
<b>Preconditions</b>	The robot is on and connected.
<b>Successful end condition</b>	The app displays states to the user.
<b>Failed end condition</b>	The app displays old states or states are unknown.
<b>Actors</b>	User, robot and app
<b>Trigger</b>	Robot sends information.


	Steps	Action
<b>Main flow:</b>	1	App receives message from robot.
	2	App unpacks the message.
	3	App correctly displays the information (see also app design document)
<b>Exception flow:</b>	1.1	App does not receive message from robot.
	1.2	Nothing changes in UI (old information stays)
	2.1	App is unable to read the message.
	2.2	App displays old information

## Class diagrams

### Robot



## State diagram - Robot





## Protocols

### Identify

When a device connects with the hotspot on the robot it must identify itself in order to get a valid connection.

<b>From device</b>	App
<b>To device</b>	Robot
<b>Description</b>	Connect and identify this device as controller.

App	Robot
Identify:CONTROLLER:01 (<action>:<device type>:<ID>)	
	ACK
ACK	

### Update information

When the robot has new information for the app it shall send it. The information includes e.g. battery level and speed.

<b>From device</b>	Robot
<b>To device</b>	App
<b>Description</b>	Sending new information

App	Robot
	Info:<long string message>
ACK	

### Instructions

When the app is connected to the robot, the user can decide to start controlling the robot. In order to establish this, the app sends the user input (instructions) to the robot.

<b>From device</b>	App
<b>To device</b>	Robot
<b>Description</b>	Sending new instruction

App	Robot
Instruction:<Direction><speed> (e.g. instruction:LeftDown50)	
	ACK

### Disconnect

When the user disconnects the app from the robot, the connection is broken and the robot goes into idle while still balancing itself.

<b>From device</b>	App
<b>To device</b>	Robot
<b>Description</b>	App disconnect from the robot.

App	Robot
Disconnect:CONTROLLER:01 (<action>:<device type>:<ID>)	
	ACK